



1. Switch on mains switch
2. Set the temperature (maximum is about 50 deg c)
3. When the temperature is reached the heater neon will go out
4. insert PCB to be etched
5. Switch on the pump
6. Inspect PCB regularly
7. When PCB is etched turn off pump

Once the tank has reached temperature the neon will cycle between off & on, this is normal.