## PRODUCT INFORMATION



## Electronic flux ISO-Flux® "ELS 3320-22"

#### Resin free No-clean flux for the wave soldering

# Electronic flux ISO-Flux<sup>®</sup> "ELS 3320-22" DIN EN 61190-1-1 / ORL0 (DIN EN 29454-1 / 2.2.3.A)

Article no.: 258320...

#### **Description**

**ISO-Flux**<sup>®</sup> "ELS 3320-22" is a resin free, halide free flux on alcohol basis for the automatic soldering of P.C.B's with standard and SMD-mounting. The flux shows very good activating properties and has excellent spreading properties on **all** common solder surfaces.

**ISO-Flux** "ELS 3320-22" has especially been developed for the purpose of an inertisation of organic surfaces as well as against blob development during the wave soldering process. Especially for photopolymere solder resist masks, for two component solder resist masks as well as untreated basis material this flux prevents through its special preparation as far as possible the corresponding development mechanism respectively an affinity at the interface.

**ISO-Flux** "ELS 3320-22" is very temperature stable and therefore very suitable for the lead-free soldering technique.

#### **Properties**

Solid content : 2,2% Acid value : 20

Density (20°C) : 0,806 g/cm³
Flash point : <12°C
Halide content : halide-free
Colour : clear as water

Thinner : VF-1

#### **Application**

**ISO-Flux** "ELS 3320-22" is especially suitable for the highly qualified production of commercial electronic and achieves with SMD-mounting best results.

The application of the flux on the P.C.B. is practicable with all well known flux procedures (e. g. foams, sprays etc.).

FELDER GMBH Löttechnik Im Lipperfeld 11 D-46047 Oberhausen Tel.: 0208 / 85035-0 Fax.: 0208 / 26080 www.felder.de info@felder.de

## PRODUCT INFORMATION



## Electronic flux ISO-Flux® "ELS 3320-22"

**ISO-Flux** "ELS 3320-22" is conceived for the soldering in the double wave as well as conceived for the soldering in the single wave.

After the soldering the circuits as far as possible free of residues. Therefore, the cleaning can be left out. The cooled down flux distinguishes itself through its well isolation properties, which are kept by the humidity demands.

A lacquer ability of the cooled down circuit with common isolation lacquers are usually given. The Applicant should convince himself of the compatibility.

## As quality security measures Als Qualitätssicherungsmaßnahmen wurden u.a. folgende Versuche durchgeführt:

<u>Isolation resistance</u> Kamm sample according to IPC-B-24

<u>Sample preparation</u> Test A, 3 Kamm sample (Blindprobe)

Test B, apply 3 Kamm sample with flux, after drying put it on the solder bath at 245 - 260°C for 4±1 seconds with

Kamm sample <u>upward</u>.

Test C, like B, but put Kamm sample downward on the

solder bath.

Result SIR-Test passed uncleaned and cleaned

**E-Corrosion** The Kamm sample of the isolation test will be stored after

4 days humidity test for further 21 days in climate 40°C / 93% rel. humidity at applied direct voltage

(+5VDC).

Result none E-Corrosion

#### **Preheat temperature**

The typical preheat temperature measured at the component side of the printed circuit, should be  $80^{\circ}\text{C}$  -  $110^{\circ}\text{C}$  (choose a preheat temperature of  $20 - 30^{\circ}\text{C}$  if a lead-free solder is applied).

#### Solder bath temperature

The ideal solder bath temperature in lead-containing solder process should not exceed 250°C.

For the lead-free soldering process we recommend a max. solder bath temperature of 280°C.

#### Solder speed

Recommendable is a speed over the solder wave of 0,8 - 1,6 m per minute.

FELDER GMBH Im Lipperfeld 11 Tel.: 0208 / 85035-0 <a href="https://www.felder.de">www.felder.de</a>
Löttechnik D-46047 Oberhausen Fax.: 0208 / 26080 <a href="mailto:unifo@felder.de">www.felder.de</a>

## PRODUCT INFORMATION



## Electronic flux ISO-Flux® "ELS 3320-22"

#### **Further advices**

**ISO-Flux** "ELS 3320-22" will be tested according to ist compatibility against the common materials used in the electronic production. A compatibility test against plastics, colours and labelling by the users is recommended.

#### **Delivery form**

10 ml Flux-.Pen 1000 ml jar 5 und 25 l canister 200 l hobbock

#### **Minimum durability**

6 months from production.

If the flux systems are open the acid value has to be measured by titration daily. This can be carried out without any great effort by the machine operator with our FELDER **Titration set**.

#### Storage advices

A storage temperature of between +5°C and +20°C is recommended.

#### **Security instructions**

Please refer to the corresponding safety data sheet.

All information about our products are the result of our long-standing experience, which we would like to pass on to our customers. Since we do not have any influence on the application with our products, please see the warranty claims in our conditions of sale because our liability is limited.

FELDER GMBH Im Lipperfeld 11 Tel.: 0208 / 85035-0 <a href="https://www.felder.de">www.felder.de</a>
Löttechnik D-46047 Oberhausen Fax.: 0208 / 26080 <a href="https://www.felder.de">www.felder.de</a>